



# SERVICE BULLETIN

NO. ARC-SB-852-007

Aircraft Restoration Corporation

3. Remove the old doors and associated actuators and hydraulic hoses. On the PA-31T2 and PA-42 and PA-42-720 airplanes remove the EMERGENCY BLOW DOWN actuators and delivery lines.

It should read:

3. Remove the old doors and associated actuators and hydraulic hoses. On the PA-31T2 and PA-42 and PA-42-720 airplanes remove the EMERGENCY BLOW DOWN gear door actuators and associated delivery lines.

Inspect the emergency landing extension system to ensure that only the gear door actuators and associated compressed air delivery lines were removed and that the emergency landing gear extension actuator and up-lock hook release actuator are still in place.

Please contact Aircraft Restoration Corp. if you have any questions concerning this Service Bulletin either by Fax (801-373-4722) or by email to: [dfronk@arcmods.com](mailto:dfronk@arcmods.com).